


6. Laser Doppler Anemometry

Introduction to principles and applications




Characteristics of LDA


- **Velocity measurements in Fluid Dynamics (gas, liquid)**
- **Up to 3 velocity components (3 beam pairs)**
- **Non-intrusive measurements (optical technique)**
- **Absolute measurement technique (no calibration required)**
- **Very high accuracy**
- **Very high spatial resolution due to small measurement volume**
- **Tracer particles (seeding) are required**

LDA - Fringe Model


- Focused Laser beams intersect and form the measurement volume
- Interference in the plane of intersection
- Pattern of bright and dark stripes/planes



Velocity = distance/time



LDA Fibre Optical System



Measurement of air flow around a helicopter rotor model in a wind tunnel




Photo courtesy of University of Bristol, UK

Measurement of water flow inside a pump model




Photo courtesy of Grundfos A/S, DK

Measurement of flow field around a 1:5 scale car model in a wind tunnel






Photo courtesy of Mercedes-Benz, Germany

Comparison of EFD and CFD results




7. Light sheet flow visualisation




Flow visualised in the vicinity of a cylinder. $Re = 2\,000$. Air bubbles in water. (Van Dyke: An Album of Fluid Motion, Parabolic Press, Stanford, California, 1982)


8. Particle Image Velocimetry (PIV)




Principle of PIV (Lecture note by Pap, E., Otto-Von-Guericke Universitaet Magdeburg, Institut für Strömungstechnik und Thermodynamik, Lehrstuhl für Strömungsmaschinen)

Radial pump simulation: comparison of simulated flow field and PIV data





PIV measurement
(Otto-Von-Guericke
Universitaet Magdeburg)



FLUENT simulation
(Dept. of Fluid Mechanics, BME)

9. Hot-Wire Anemometry




- **Purpose:**
to measure mean and fluctuating variables in fluid flows (velocity, temperature, etc.): mean velocity, turbulence characteristics

TURBULENCE RESEARCH (LABORATORY)

Anemometer signal output

The thermal anemometer provides an analogue output which represents the velocity in a point. A velocity information is thus available anytime.

Note that LDA signals occur at random, while PIV signals are timed with the frame grapping of illuminated particles.





Principles of operation

- Consider a thin wire mounted to supports and exposed to a velocity U .


When a current is passed through wire, heat is generated ($I^2 R_w$). In equilibrium, this must be balanced by heat loss (primarily convective) to the surroundings \leftrightarrow **velocity** of gas

- Constant temperature anemometry: sensor resistance, i.e. sensor temperature is kept constant by electric heating \leftrightarrow the velocity of gas is deduced from the heating power







1D



1D film probe



2D X-probe



3D tri-axial probe